





Azimuths to Bearings



From the traverse shown below compute the azimuth and bearing of side BC



Compute the interior angle at B

