
# Measuring Elevation

- Elevation refers to the height above or below a fixed geographic reference point.
- In most cases, we use the Earth's sea level as our reference point, but in some cases, the ground level is used as the reference point.



Τ.

3

# Measuring Elevation

- > Elevation plays a crucial part in everyday life.
- In engineering, elevation is used to determine the center of gravity and the type of materials to be used.
- The elevation of a particular place can also help predict and prevent disasters such as flooding.

2

# Measuring Elevation



Mississippi River at flood stage ~ 217 ft. above sea level

# Measuring Elevation



Mississippi River at flood stage ~ 227 ft. above sea level

4

6

# **Measuring Elevation**



Mississippi River at flood stage ~ 237 ft. above sea level

# **Measuring Elevation**

- Humans adapt to their environment, as some are adapted to higher elevations while others are adapted to lower elevations.
- Most of the world's population lives in coastal regions with elevations of 500 feet or less.
- The people of Tibet in Central Asia are adapted to living at 17,500 ft., where crops cannot grow, and the oxygen is extremely thin.

# Measuring Elevation

- Elevation refers to the height above or below a fixed geographic reference point.
- In most cases, we use the Earth's sea level as our reference point, but in some cases, the ground level is used as the reference point.
- One method for measuring elevation is to use differential leveling.

# **Differential Leveling**

### Importance of Vertical Positions

- A vertical position is the height of a point relative to some reference surface, such as mean sea level, a geoid, or an ellipsoid.
- The roughly 600,000 vertical control points in the U.S. National Spatial Reference System (NSRS) are referenced to the North American Vertical Datum of 1988 (NAVD 88).





7

# **Differential Leveling**

### Importance of Vertical Positions

- Surveyors created the National Geodetic Vertical Datum of 1929 (NGVD 29, the predecessor to NAVD 88) by calculating the average height of the sea at all stages of the tide at 26 tidal stations over 19 years
- Surveyors extended the control network inland using a surveying technique called leveling.



**Differential Leveling** 

### Importance of Leveling

- > The determination of elevations is called *leveling*
- Measuring the relative change in elevation is a comparatively simple process
- Precise and accurate control of relative elevations is critical to most construction projects



9

10

# **Differential Leveling**

### The Level

- > A level consists of a high-powered telescope
- The level is attached to a spirit or bubble level that keeps the line of sight of the telescope horizontal







# Differential Leveling


### **Level Instrument**










































### **Differential Leveling** Computation of Elevations - Find Elevation of BM<sub>2</sub> Н Elevation BM. 12.64 112.64 100.00 10.88 120.41 3.11 109.53 TP. TP<sub>2</sub> 9.72 127.57 2.56 117.85 BM-3.10 124.47





**Differential Leveling** Computation of Elevations - Find Elevation of BM<sub>2</sub> Check the summation of the backsight and the foresight with the change in elevation Point BS Н FS Elevation 112.64 BM. 12.64 100.00 TP 10.88 120.41 3.11 109.53 TP 9.72 127.57 2.56 117.85 BM-3.10 124.47 +33.24 Change in elevation = 33.24 - 8.77 = 24.47


28


26


# Differential Leveling The initial backsight (BS) is taken to a point of known elevation The backsight reading is added to the elevation of the known point to compute the height of the instrument (HI) The level may be moved to a temporary point called a turning point (TP) The elevation of a point is the height of the instrument (HI) minus the foresight (FS)

















# **Differential Leveling**

### **Suggestions for Good Leveling**

- > Anchor tripod legs firmly
- > Check the bubble level before and after each reading
- > Take as little time as possible between BS and FS
- > Try to keep the distance to the BS and the FS equal
- > Provide the rodperson with a level for the rod

