

Importance of Concrete

Concrete is the single most widely used material in the world.

Designing Concrete Mixtures

There are three phases in the development of a concrete mixture: specifying, designing, and proportioning

```

    graph LR
      subgraph INPUT
        I1[Physical dimensions of concrete element]
        I2[Construction methods]
        I3[Service environment]
        I4[Structural design]
      end
      subgraph OUTPUT
        O1[Maximum nominal aggregate size]
        O2[Slump (approximate indicator of workability)]
        O3[Percent air void parameters]
        O4[Cement type w/c, w/cm]
        O5["fc, fr, fsp, fc"]
      end
      I1 --> O1
      I1 --> O2
      I2 --> O1
      I2 --> O2
      I3 --> O3
      I3 --> O4
      I4 --> O5
  
```

Designing Concrete Mixtures

There are three phases in the development of a concrete mixture: specifying, designing, and proportioning


Mixture proportions	
Water	kg/m ³ (lb/yd ³)
Cement	kg/m ³ (lb/yd ³)
Fly ash	kg/m ³ (lb/yd ³)
Coarse aggregate	kg/m ³ (lb/yd ³)
Intermediate aggregate	kg/m ³ (lb/yd ³)
Fine aggregate	kg/m ³ (lb/yd ³)
Air content	%
Air-entraining admixture	ml (fl oz)
Water-reducing admixture	ml (fl oz)

ACI Mix Design

- The most common method used in North America is that established by **ACI Recommended Practice 211.1**
- Any mix design procedure will provide a first approximation of the proportions and must be checked by trial batches.
- Local characteristics in materials should be considered.
- The following sequence of steps should be followed:
 - (1) determine the job parameters - aggregate properties, maximum aggregate size, slump, w/c ratio, admixtures,
 - (2) calculation of batch weight, and
 - (3) adjustments to batch weights based on trial mix.

ACI Mix Design

- Water/cement ratio (w/c ratio) theory states that for a given combination of materials and as long as workable consistency is obtained, the strength of concrete at a given age depends on the w/c ratio.
- The lower the w/c ratio, the higher the concrete strength.
- Whereas strength depends on the w/c ratio, economy depends on the percentage of aggregate present that would still give a workable mix.
- The aim of the designer should always be to get concrete mixtures of optimum strength at minimum cement content and acceptable workability.



ACI Mix Design

Air-Entrained Concrete

- One of the greatest advances in concrete technology was the development of air-entrained concrete in the late 1930s.
- Today, air entrainment is recommended for nearly all concretes, principally to improve resistance to freezing when exposed to water and deicing chemicals.
- Air-entrained concrete contains billions of microscopic air cells
- These relieve internal pressure on the concrete by providing tiny chambers for the expansion of water when it freezes.




ACI Mix Design

- Once the w/c ratio is established and the workability or consistency needed for the specific design is chosen, the rest should be simple manipulation with diagrams and tables based on large numbers of trial mixes.
- Such diagrams and tables allow an estimate of the required mix proportions for various conditions and permit predetermination on small unrepresentative batches.

ACI Mix Design

The flowchart is a representation of the principal properties of "good" concrete

- cement
- w/c ratio
- aggregate
- cement paste and aggregate
- mixing
- placement and handling of fresh concrete
- curing



ACI Mix Design

Basic Considerations

- **Economy** -- The material costs are most important in determining the relative costs of different mixes.
- The labor and equipment costs, except for special concretes, are generally independent for the mix design.
- Since cement is more expensive than aggregate, it is clear that cement content should be minimized.
- This can be accomplished by
 1. using the lowest slump that will permit handling,
 2. using a good ratio of coarse to fine aggregate, and
 3. possible use of admixtures.

ACI Mix Design

Basic Considerations

- **Workability** -- A good mix design must be capable of being placed and compacted, with minimal bleeding and segregation, and be finishable.
- Water requirements depend on the aggregate rather than the cement characteristics.
- Workability should be improved by redesigning the mortar faction rather than simply adding more water.

ACI Mix Design

Basic Considerations

- **Strength and Durability** -- In general, the minimum compressive strength and a range of w/c ratios are specified for a given concrete mix.
- Possible requirements for resistance to freeze-thaw and chemical attack must be considered.
- Therefore, a balance or compromise must be made between strength and workability.

ACI Mix Design

- A measure of the degree of consistency and extent of workability is the **slump**.
- In the slump test the plastic concrete specimen is formed into a conical metal mold as described in ASTM Standard C-143.
- The mold is lifted, leaving the concrete to "slump," that is, to spread or drop in height.

ACI Mix Design

Process of measuring the slump of fresh concrete




ACI Mix Design

Process of measuring the slump of fresh concrete



ACI Mix Design

This drop in height is the slump measure of the degree of workability of the mix.



ACI Mix Design


Here are some examples of different measures of slump:





ACI Mix Design

The flowchart is a representation of the principal properties of ACI mix design of concrete

- workability – slump
- water and air content
- w/c ratio
- cement
- coarse aggregate
- fine aggregate
- moisture adjustment
- trial mix





ACI Mix Design

Mix Design Procedures

5. Water/cement ratio - This component is governed by strength and durability requirements

- (a) Strength -- Without strength vs. w/c ratio data for a certain material, a conservative estimate can be made for the accepted 28-day compressive strength from Table 3.
- (b) Durability -- If there are severe exposure conditions, such as freezing and thawing, exposure to seawater, or sulfates, the w/c ratio requirements may have to be adjusted.

ACI Mix Design

Mix Design Procedures

Relationship between water/cement ratio and compressive strength of concrete

28-day Compressive Strength (psi)	Non-AE	AE
2,000	0.82	0.74
3,000	0.68	0.59
4,000	0.57	0.48
5,000	0.48	0.40
6,000	0.41	0.32
7,000	0.33	---

ACI Mix Design

Mix Design Procedures

6. Calculation of cement content -- Once the water content and the w/c ratio is determined, the amount of cement per unit volume of the concrete is found by dividing the estimated water content by the w/c ratio.

$$\text{weight of cement} = \frac{\text{weight of water}}{w/c}$$

However, a minimum cement content is required to ensure good finishability, workability, and strength.

ACI Mix Design

Mix Design Procedures

7. Estimation of coarse aggregate content - The percent of coarse aggregate to concrete for a given maximum size and fineness modulus is given by Table 4.

The value from the table multiplied by the dry-rodded unit weight (the oven-dry (OD) weight of coarse aggregate required per cubic foot of concrete).

To convert from OD to saturated surface dry (SSD) weights, multiply by [1 + absorption capacity (AC)].

ACI Mix Design

Mix Design Procedures

Volume of dry-rodded coarse aggregate per unit volume of concrete for different coarse aggregates and fineness moduli of fine aggregates

Max Aggregate (in.)	Fineness Modulus						
	2.4	2.5	2.6	2.7	2.8	2.9	3
0.375	0.50	0.49	0.48	0.47	0.46	0.45	0.44
0.500	0.59	0.58	0.57	0.56	0.55	0.54	0.53
0.750	0.66	0.65	0.64	0.63	0.62	0.61	0.60
1.000	0.71	0.70	0.69	0.68	0.67	0.66	0.65
1.500	0.75	0.74	0.73	0.72	0.71	0.70	0.69
2.000	0.78	0.77	0.76	0.75	0.74	0.73	0.72
3.000	0.82	0.81	0.80	0.79	0.78	0.77	0.76
6.000	0.87	0.86	0.85	0.84	0.83	0.82	0.81

ACI Mix Design

Mix Design Procedures

The coarse aggregate will occupy:

$$\boxed{} \times 27 \frac{\text{ft.}^3}{\text{yd.}^3} = \boxed{} \frac{\text{ft.}^3}{\text{yd.}^3}$$

Value from Table 4

The OD weight of the coarse aggregate

$$\boxed{} \frac{\text{ft.}^3}{\text{yd.}^3} \times \boxed{} \frac{\text{lb.}}{\text{ft.}^3} = \boxed{} \frac{\text{lb.}}{\text{yd.}^3}$$

Dry-Rodded Unit Weight

ACI Mix Design

Mix Design Procedures

Volume of dry-rodded coarse aggregate per unit volume of concrete for different coarse aggregates and fineness moduli of fine aggregates

ACI Mix Design

Mix Design Procedures

8. Estimation of fine aggregate content

-- There are two standard methods to establish the fine aggregate content, the mass method and the volume method. We will use the "volume" method.

- > "Volume" Method -- This method is the preferred method, as it is a somewhat more exact procedure
- > The volume of fine aggregates is found by subtracting the volume of cement, water, air, and coarse aggregate from the total concrete volume.

ACI Mix Design

Mix Design Procedures

8. Estimation of fine aggregate content

water (ft ³)	$\frac{\text{water (lb)}}{62.4 \frac{\text{lb}}{\text{ft}^3}}$
Cement (ft ³)	$\frac{\text{cement (lb)}}{3.15 \times 62.4 \frac{\text{lb}}{\text{ft}^3}}$
Coarse Aggregate (ft ³)	$\frac{\text{coarse aggregate (lb)}}{SG_{CA} \times 62.4 \frac{\text{lb}}{\text{ft}^3}}$
Air (ft ³)	$\text{air (\%)} \times 27 \frac{\text{ft}^3}{\text{yd}^3}$

ACI Mix Design

Mix Design Procedures

> Therefore, the fine aggregate must occupy a volume of:

$$27 \text{ ft.}^3 - \boxed{\text{Volume}} \text{ ft.}^3 = \boxed{\text{Volume}_{FA}} \text{ ft.}^3$$

> The SSD weight of the fine aggregate is:

$$\boxed{\text{Volume}_{FA}} \text{ ft.}^3 \times \boxed{SG_{FA}} \times 62.4 \frac{\text{lb.}}{\text{ft.}^3} = \boxed{FA_{SSD}} \text{ lb.}$$

Specific Gravity of Fine Aggregate Unit Weight of Water

ACI Mix Design

Mix Design Procedures

9. **Adjustment for moisture in the aggregate** -- The water content of the concrete will be affected by the moisture content of the aggregate.

ACI Mix Design

Mix Design Procedures

9. **Adjustment for moisture in the aggregate** -- The water content of the concrete will be affected by the moisture content of the aggregate.

ACI Mix Design

Mix Design Procedures

9. **Adjustment for moisture in the aggregate** -- The water content of the concrete will be affected by the moisture content of the aggregate.

$Moisture\ content\ (MC) = AC + SM$

ACI Mix Design

Mix Design Procedures

9. **Adjustment for moisture in the aggregate**
The weight of aggregate from the stock pile is:

$$Weight_{Stock\ Pile} = Weight_{OD} (1 + MC)$$

The change in the weight water due to the moisture of the aggregate from the stock pile is:

$$\Delta Weight_{Water} = Weight_{OD} (SM)$$

$$Adjusted\ Weight_{Water} = Weight_{Water} - \Delta Weight_{Water}$$

ACI Mix Design

Mix Design Procedures

10. **Trial batch** -- Using the proportions developed in the preceding steps, mix a trial batch of concrete using only as much water as is needed to reach the desired slump (but not exceeding the permissible w/c ratio).

ACI Mix Design

Mix Design Procedures


10. **Trial batch**

The fresh concrete should be tested for slump, unit weight, yield, air content, and its tendencies to segregate, bleed, and finishing characteristics. Also, hardened samples should be tested for compressive and flexural strength.

ACI Mix Design

Information for concrete mixtures using particular ingredients can be plotted to illustrate the relationship between ingredients and properties:

- Slump
- Aggregate Size
- w/c
- Cement content



End of ACI Mix Design

Questions?

