


INELASTIC BEHAVIOR OF MATERIALS AND STRUCTURES



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 1

Inelastic Behavior of Materials and Structures

- Illustrates inelastic behavior of materials and structures
- Explains why inelastic response may be necessary
- Explains the "equal displacement" concept
- Introduces the concept of inelastic design response spectra
- Explains how inelastic behavior is built into the *NEHRP Recommended Provisions* and ASCE 7-05



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 2

Importance in Relation to ASCE 7-05

- Derivation and explanation of the *response reduction factor, R*
- Derivation and explanation of the *displacement amplification factor, C_d*
- Derivation and explanation of the *overstrength factor, Ω_o*



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 3

Inelastic Behavior of Structures


From material
↓
to cross section
↓
to critical region
↓
to structure



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 4


Idealized Inelastic Behavior From Material.....



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 5


Stress-Strain Relationships for Steel



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 6


Stress-Strain Relationships for Steel



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 7


Stress-Strain Relationships for Concrete (Unconfined and Confined)



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 8


Concrete Confinement




Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 9

Unconfined




Confined



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 10

Benefits of Confinement




Olive View Hospital, 1971 San Fernando Valley earthquake



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 11


Idealized Inelastic Behavior To Section.....



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 12

Idealized Inelastic Behavior To Section.....




NOTE: $\mu_\phi \leq \mu_\epsilon$



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 13


Software for Moment - Curvature Analysis "XTRACT"



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 14


Idealized Inelastic Behavior To Critical Region and Member



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 15

Idealized Inelastic Behavior To Critical Region and Member




NOTE: $\mu_{\bar{\theta}} \leq \mu_\theta \leq \mu_\phi$



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 16


Critical Region Behavior of a Steel Girder



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 17

Idealized Inelastic Behavior To Structure.....



Note: $\mu_\Delta \leq \mu_{\bar{\theta}}$



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 18

Loss of Ductility Through Hierarchy

Strain $\mu_\epsilon = 100$

Curvature $\mu_\phi = 12$ to 20

Rotation $\mu_\theta = 8$ to 14

Displacement $\mu_\Delta = 4$ to 10



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 19

Ductility and Energy Dissipation Capacity


- System ductility of 4 to 6 is required for acceptable seismic behavior.
- Good hysteretic behavior requires ductile materials. However, ductility in itself is insufficient to provide acceptable seismic behavior.
- Cyclic energy dissipation capacity is a better indicator of performance.



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 20


Response Under Reversed Cyclic "Loading"



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 21


Laboratory Specimen Under Cyclic Deformation Loading



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 22


Laboratory Specimen Under Cyclic Deformation Loading



Instructional Material Complementing FEMA 451, Design Examples



Inelastic Behaviors 6 - 23

Hysteretic Behavior



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 24



Ductility and Energy Dissipation Capacity

- The structure should be able to sustain several cycles of inelastic deformation without significant loss of strength.
- Some loss of stiffness is inevitable, but excessive stiffness loss can lead to collapse.
- The more energy dissipated per cycle without excessive deformation, the better the behavior of the structure.

Instructional Material Complementing FEMA 451, Design Examples Inelastic Behaviors 6 - 27

Ductility and Energy Dissipation Capacity

- The art of seismic-resistant design is in the details.
- With good detailing, structures can be designed for force levels significantly lower than would be required for elastic response.

Instructional Material Complementing FEMA 451, Design Examples Inelastic Behaviors 6 - 28

Why Is Inelastic Response Necessary? Compare the Wind and Seismic Design of a Simple Building

Building properties:
 Moment resisting frames
 Density $\rho = 8$ pcf
 Period $T = 1.0$ sec
 Damping $\xi = 5\%$
 Soil Site Class "B"

Wind:
 100 mph Exposure C

Earthquake:
 Assume $S_{D1} = 0.48g$

Instructional Material Complementing FEMA 451, Design Examples Inelastic Behaviors 6 - 29

Wind:

100 mph fastest Exposure C

Velocity pressure $q_s = 25.6$ psf
 Gust/exposure factor $C_e = 1.25$
 Pressure coefficient $C_q = 1.3$
 Load factor for wind = 1.3


Total wind force on 120-foot face:
 $V_{W120} = 62.5 \times 120 \times 25.6 \times 1.25 \times 1.3 \times 1.3 / 1000 = \mathbf{406 \text{ kips}}$

Total wind force on 90-foot face:
 $V_{W90} = 62.5 \times 90 \times 25.6 \times 1.25 \times 1.3 \times 1.3 / 1000 = \mathbf{304 \text{ kips}}$

Instructional Material Complementing FEMA 451, Design Examples Inelastic Behaviors 6 - 30

Earthquake:

Building weight, $W = 120 \times 90 \times 62.5 \times 8 / 1000 = 5400$ kips



$$V_{EQ} = C_S W$$

$$C_S = \frac{S_{D1}}{T(R/I)} = \frac{0.48}{1.0(1.0/1.0)} = 0.480$$

Total **ELASTIC** earthquake force (in each direction):
 $V_{EQ} = 0.480 \times 5400 = 2592$ kips



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 31

Comparison: Earthquake vs. Wind

$$\frac{V_{EQ}}{V_{W120}} = \frac{2592}{406} = 6.4$$

$$\frac{V_{EQ}}{V_{W90}} = \frac{2592}{304} = 8.5$$

- ELASTIC earthquake forces 6 to 9 times wind!
- Virtually impossible to obtain economical design



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 32

How to Deal with Huge Earthquake Force?

- Isolate structure from ground (base isolation)
- Increase damping (passive energy dissipation)
- Allow controlled inelastic response


Historically, building codes use **inelastic response procedure**.
 Inelastic response occurs through structural **damage** (yielding).
 We must control the damage for the method to be successful.



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 33


Assume Frame Is Designed for Wind "Pushover" Analysis Predicts Strength = 500 k



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 34


How Will Frame Respond During 0.4g El Centro Earthquake?



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 35

Response Computed by NONLIN



Maximum displacement:
4.79"

Maximum shear force:
542 k


Number of yield events:
15



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 36

Response Computed by NONLIN



Yield displacement = $500/550 = 0.91$ inch

$$\text{Ductility Demand} = \frac{\text{Maximum Displacement}}{\text{Yield Displacement}} = \frac{4.79}{0.91} = 5.26$$



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 37

Interim Conclusion (The Good News)

The frame, designed for a wind force that is 15% of the ELASTIC earthquake force, can survive the earthquake if:

- It has the capability to undergo **numerous cycles of INELASTIC deformation.**
- It has the capability to **deform at least 5 to 6 times the yield deformation.**
- It suffers **no appreciable loss of strength.**

REQUIRES ADEQUATE DETAILING



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 38

Interim Conclusion (The Bad News)

As a result of the large displacements associated with the inelastic deformations, the structure will suffer considerable structural and nonstructural damage.

- This damage must be controlled by adequate detailing and by limiting structural deformations (drift).



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 39

Development of "Equal Displacement" Concept of Seismic Resistant Design

Concept used by:

IBC
NEHRP
ASCE-7 } In association with "force based" design concept. Used to predict design forces and displacements

FEMA 273 } In association with static pushover analysis. Used to predict displacements at various performance points.



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 40

The Equal Displacement Concept

"The displacement of an inelastic system, with stiffness K and strength F_y , subjected to a particular ground motion, is approximately equal to the displacement of the same system responding elastically."


(The displacement of a system is independent of the yield strength of the system.)



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 41


Repeat Analysis for Various Yield Strengths (All other parameters stay the same)



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 42

Constant Displacement Idealization of Inelastic Response



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 43

Equal Displacement Idealization of Inelastic Response


- For design purposes, it may be assumed that inelastic displacements are equal to the displacements that would occur during an elastic response.
- The required force levels under inelastic response are much less than the force levels required for elastic response.



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 44


Equal Displacement Concept of Inelastic Design



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 45

Equal Displacement Concept of Inelastic Design




Ductility supply MUST BE $>$ ductility demand $= \frac{5.77}{0.91} = 6.34$



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 46



Using response spectra, estimate **elastic** force demand F_E
 Estimate ductility supply, μ , and determine **inelastic** force demand $F_I = F_E / \mu$. **Design structure for F_I .**
 Compute reduced displacement, d_R , and multiply by μ to obtain true inelastic displacement, d_I . **Check drift using d_I .**



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 47

ASCE 7 Approach

Use basic elastic spectrum but, for strength, divide all pseudoacceleration values by R , a response modification factor that accounts for:

- Anticipated ductility supply
- Overstrength
- Damping (if different than 5% critical)
- Past performance of similar systems
- Redundancy




Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 48

Ductility/Overstrength

FIRST SIGNIFICANT YIELD



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 49

First Significant Yield is the level of force that causes complete plastification of at least the most critical region of the structure (e.g., formation of the first plastic hinge).


The **design strength** of a structure is equal to the resistance at first significant yield.



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 50


Overstrength (1)



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 51


Overstrength (2)



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 52

Overstrength (3)



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 53

Sources of Overstrength

- Sequential yielding of critical regions
- Material overstrength (actual vs specified yield)
- Strain hardening
- Capacity reduction (ϕ) factors
- Member selection




Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 54

Definition of Overstrength Factor Ω


$$\text{Overstrength Factor } \Omega = \frac{\text{Apparent Strength}}{\text{Design Strength}}$$



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 55

Definition of Ductility Reduction Factor R_d




Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 56

Definition of Ductility Reduction Factor

$$\text{Ductility Reduction } R_d = \frac{\text{Elastic Strength Demand}}{\text{Apparent Strength}}$$



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 57

Definition of Response Modification Coefficient R

$$\text{Overstrength Factor } \Omega = \frac{\text{Apparent Strength}}{\text{Design Strength}}$$

$$\text{Ductility Reduction } R_d = \frac{\text{Elastic Strength Demand}}{\text{Apparent Strength}}$$


$$R = \frac{\text{Elastic Strength Demand}}{\text{Design Strength}} = R_d \Omega$$



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 58


Definition of Response Modification Coefficient R



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 59

Definition of Deflection Amplification Factor Coefficient C_d



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 60

ASCE 7 Approach for Displacements

Determine design forces: $V = C_s W$, where C_s includes ductility/overstrength reduction factor R .

Distribute forces vertically and horizontally and compute displacements using linear elastic analysis.

Multiply computed displacements by C_d to obtain estimate of true inelastic response.



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 61

Examples of Design Factors for Steel Structures ASCE 7-05

	R	Ω_o	R_d	C_d
Special Moment Frame	8	3	2.67	5.5
Intermediate Moment Frame	4.5	3	1.50	4.0
Ordinary Moment Frame	3.5	3	1.17	3.0
Eccentric Braced Frame	8	2	4.00	4.0
Eccentric Braced Frame (Pinned)	7	2	3.50	4.0
Special Concentric Braced Frame	6	2	3.00	5.0
Ordinary Concentric Braced Frame	3.25	2	1.25	3.25
Not Detailed	3	3	1.00	3.0

Note: R_d is ductility demand ONLY IF Ω_o is achieved.



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 62

Examples of Design Factors for Reinforced Concrete Structures ASCE 7-05

	R	Ω_o	R_d	C_d
Special Moment Frame	8	3	2.67	5.5
Intermediate Moment Frame	5	3	1.67	4.5
Ordinary Moment Frame	3	3	1.00	2.5
Special Reinforced Shear Wall	5	2.5	2.00	5.0
Ordinary Reinforced Shear Wall	4	2.5	1.60	4.0
Detailed Plain Concrete Wall	2	2.5	0.80	2.0
Ordinary Plain Concrete Wall	1.5	2.5	0.60	1.5


Note: R_d is Ductility Demand ONLY IF Ω_o is Achieved.



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 63


ASCE 7 Elastic Spectra as Adjusted for Ductility and Overstrength



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 64


Using Modified ASCE 7 Spectrum to Determine Force Demand



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 65

Using Modified ASCE-7 Spectrum to Determine Displacement Demand




Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 66

Displacements must be multiplied by factor C_d because displacements based on reduced force **would be too low**

$$\Delta_{INELASTIC} = C_d \times \Delta_{REDUCEDELASTIC}$$



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 67

“Equal displacement” approach may not be applicable at very low period values.




Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 68

Equal Energy Concept (Applicable at Low Periods)

ELASTIC ENERGY



$$E_E = 0.5 F_E \frac{F_E}{F_I} \delta_y = 0.5 \delta_y \frac{F_E^2}{F_I}$$




Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 69

Equal Energy Concept (Applicable at Low Periods)

INELASTIC ENERGY



$$E_I = F_I \delta_u - 0.5 F_I \delta_y = F_I \delta_y (\mu - 0.5)$$




Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 70

Equal Energy Concept (Applicable at Low Periods)

Assuming $E_E = E_I$:




$$\frac{F_E}{F_I} = \sqrt{2\mu - 1}$$



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 71

Newmark Inelastic Spectrum (for Psuedoacceleration)



Elastic:

Inelastic:

EqualDisp

Equal Energy

Transition



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 72

Newmark's Inelastic Design Response Spectrum


To obtain inelastic displacement spectrum, multiply the spectrum shown in previous slide by μ (for all periods).



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 73


Inelastic Design Response Spectrum for Acceleration & Displacement



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 74

At very low periods, the ASCE 7 spectrum does not reduce to ground acceleration so this partially compensates for "error" in equal displacement assumption at low period values.



Note: FEMA 273 has explicit modifications for computing "target at low periods."



Instructional Material Complementing FEMA 451, Design Examples

Inelastic Behaviors 6 - 75